



---

# ***DEM-DAI3052A***

*User's Guide*

---

***September 2006***

***DAP***

---

***SLEU079***

**DEM-DAI3052A**

***User's Guide***

Literature Number: SLEU079  
September 2006



# Contents

<b>1</b>	<b>Description</b>	<b>5</b>
1.1	Block Diagram.....	6
1.2	Basic Connection and Operation .....	7
1.2.1	Basic Connections and Configurations .....	7
1.2.2	Configuration Controls .....	8
1.2.3	DEM-DAI3052A EVM Operation .....	11
1.3	Typical Performance and Measurement Example .....	12
<b>2</b>	<b>Schematics and Printed Circuit Boards</b>	<b>19</b>
2.1	DEM-DAI3052A Schematics .....	20
2.2	DEM-DAI3052A Bill of Materials (BOM).....	24
2.3	DEM-DAI3052A Printed Circuit Boards .....	27

---

## List of Figures

1-1	DEM-DAI3052A Block Diagram.....	6
2-1	DEM-DAI3052A Power and Interface Section.....	20
2-2	DEM-DAI3052A Digital Section (Digital Audio Interface) .....	21
2-3	DEM-DAI3052A Analog Section.....	22
2-4	DEM-DAI3052A DUT Section .....	23
2-5	DEM-DAI3052A Top Silkscreen .....	27
2-6	DEM-DAI3052A Top Copper .....	28
2-7	DEM-DAI3052A Bottom Copper.....	29
2-8	DEM-DAI3052A Form, Dimension, and Drill.....	30

## List of Tables

1-1	CN057: 3.3-V Power Source Selection .....	8
1-2	SW001: SPDIF Input Selection .....	8
1-3	SW051: SPDIF Output Selection .....	8
1-4	SW052: SPDIF Output Source Signal Selection .....	8
1-5	SW004: DIR1703 Clock Source Selection .....	8
1-6	SW003: DIR1703 System Clock Selection .....	8
1-7	SW005: DIT4096 Master Clock Selection .....	8
1-8	JP001: DIR1703 Crystal Selection for Crystal Mode System Clock and Default Sampling Frequency .....	9
1-9	SW003: DIR1703 Format Selection .....	9
1-10	SW005: DIT4096 Format Selection .....	9
1-11	SW006: DIT4096 Channel Status Information Control .....	9
1-12	SW053: Mode Control.....	9
1-13	JP051: DOUTS or MDO Setting for Mode Control.....	10
1-14	JP109: DUT (PCM3052A) V <sub>CC</sub> Supply Voltage Selection .....	10
1-15	JP110: MIC Input Configuration .....	10
1-16	JP101-104: Lineout LPF Selection.....	10
1-17	JP105, JP106: ADC Input Level Selection.....	10
1-18	JP107: Bridge for PCM Audio Interface .....	10
1-19	JP108: Bridge for Mode Control Interface .....	10

## Description

The DEM-DAI3052A is an evaluation board for the PCM3052A, a 96-kHz, 24-bit stereo audio coder/decoder (codec), with digital audio interface receiver/transmitter, optical and coaxial interface, onboard clock generator, -6-dB amplifier with LPF for ADC and 4-dB amplifier with LPF for DAC, switches or jumpers for mode or clock control, and interface connector with PC for serial mode control.


The DEM-DAI3052A operates under 5-V and ±15-V analog power supplies, with 1-Vrms or 2-Vrms unbalanced analog signal input and 2-Vrms unbalanced analog signal output.

Topic	Page
1.1 Block Diagram.....	6
1.2 Basic Connection and Operation .....	7
1.3 Typical Performance and Measurement Example .....	12

## Block Diagram

---

### 1.1 Block Diagram



**Figure 1-1. DEM-DAI3052A Block Diagram**

## 1.2 Basic Connection and Operation

### 1.2.1 Basic Connections and Configurations

- Install REGTEST\_I2C and other programs attached to the EVM into the appropriate folder of the PC that is used to control this EVM.
- Confirm EVM settings. SW053 must be all OFF (High). JP051 SCL, SDA, MDO, and DOUTS must be OFF, OFF, OFF, and ON, respectively.
- Connect the 5-V and  $\pm$ 15-V power supplies to  $V_{CC}$ ,  $\pm AV_{CC}$ , and GND on CN051–CN055. If external 3.3 V is used on CN056, jumper CN057 must be removed. The  $\pm$ 15-V power supplies are required for 2-Vrms input and 2-Vrms output.
- Connect the SPDIF input to CN059 (coaxial) or U053 (optical) and output to CN058 (coaxial) or U052 (optical), and select coaxial or optical for SPDIF input and output using SW001 and SW051. Also, select the SPDIF output source from the analog-to-digital converter (ADC) output or the digital-to-analog converter (DAC) input using SW052.
- Select the system clock source from x'tal or SPDIF input recover clock using SW004, select the system clock using SW003 SCF1/0 for DIR1703 and using SW005 CLK1/0 for DIT4096, and select the system clock frequency for x'tal mode using JP001 setting.
- Set the interface format (24-bit I<sup>2</sup>S) using SW003 FMT1/0 for DIR1703 and using SW005 FMT1/0 for DIT4096.
- Set the channel status for DIT4096 using SW006 if required. (It is not required for PCM3052A evaluation.)
- Select the analog input/output configuration according to application interface, specifically, select the DUT PCM3052A  $V_{CC}$  from 5 V or 4.5 V using JP109, the Mic input configuration of single ended or differential using JP110, the ADC input full scale from 2 Vrms or 1 Vrms using JP105/6, and the DAC output LPF band width from 20 kHz or 40 kHz using JP101-104.

## 1.2.2 Configuration Controls

**Table 1-1. CN057: 3.3-V Power Source Selection**

CN057	DESCRIPTION
OFF	3.3 V must be supplied on CN056.
ON	3.3 V must be supplied by on board regulator, U051 (default).

**Table 1-2. SW001: SPDIF Input Selection**

SW001	DESCRIPTION
COAX	Select coaxial connector as SPDIF input (default)
OPT	Select optical connector as SPDIF input

**Table 1-3. SW051: SPDIF Output Selection**

SW051	DESCRIPTION
COAX	Select coaxial connector as SPDIF output
OPT	Select optical connector as SPDIF output (default)

**Table 1-4. SW052: SPDIF Output Source Signal Selection**

SW052	DESCRIPTION
REC	Select DOUTS of PCM3052A, DAC input
DIT	Select DIT4096 output, ADC output (default)

**Table 1-5. SW004: DIR1703 Clock Source Selection**

SW004	DESCRIPTION
X'tal	SCKO (system clock out) is generated from crystal clock.
PLL	SCKO is generated from SPDIF recovery clock.
AUTO	Source clock of SCKO is automatically selected according to PLL lock state (default).

**Table 1-6. SW003: DIR1703 System Clock Selection**

SW003		DESCRIPTION
SCF1	SCF0	
OFF (L)	OFF (L)	128 f <sub>S</sub>
OFF (L)	ON (H)	256 f <sub>S</sub> (Default)
ON (H)	OFF (L)	384 f <sub>S</sub>
ON (H)	ON (H)	512 f <sub>S</sub>

**Table 1-7. SW005: DIT4096 Master Clock Selection**

SW005		DESCRIPTION
CLK1	CLK0	
OFF (H)	OFF (H)	512 f <sub>S</sub>
OFF (H)	ON (L)	384 f <sub>S</sub>
ON (L)	OFF (H)	256 f <sub>S</sub> (default)
ON (L)	ON (L)	Unused

**Table 1-8. JP001: DIR1703 Crystal Selection for Crystal Mode System Clock and Default Sampling Frequency**

JP001	DESCRIPTION
OPEN	6.144/12.288/18.432/24.576 MHz for 128 f <sub>S</sub> /256 f <sub>S</sub> /384 f <sub>S</sub> /512 f <sub>S</sub> , 48 kHz
CSBIT	12.288/24.576/36.864/49.152 MHz for 128 f <sub>S</sub> /256 f <sub>S</sub> /384 f <sub>S</sub> /512 f <sub>S</sub> , 96 kHz (default)
URBIT	11.2896/22.5792/33.8688/45.158 MHz for 128 f <sub>S</sub> /256 f <sub>S</sub> /384 f <sub>S</sub> /512 f <sub>S</sub> , 88.2 kHz
EMFLG	5.6448/11.2896/16.9344/22.5792 MHz for 128 f <sub>S</sub> /256 f <sub>S</sub> /384 f <sub>S</sub> /512 f <sub>S</sub> , 44.1 kHz
BFRAME	4.096/8.192/12.288/16.384 MHz for 128 f <sub>S</sub> /256 f <sub>S</sub> /384 f <sub>S</sub> /512 f <sub>S</sub> , 32 kHz

**Table 1-9. SW003: DIR1703 Format Selection**

SW003		DESCRIPTION
FMT1	FMT0	
OFF (L)	OFF (L)	16 bits MSB first, right justified
OFF (L)	ON (H)	24 bits MSB first, right justified
ON (H)	OFF (L)	24 bits MSB first, left justified
ON (H)	ON (H)	24 bits MSB first, I <sup>2</sup> S format (default)

**Table 1-10. SW005: DIT4096 Format Selection**

SW005		DESCRIPTION
FMT1	FMT0	
OFF (H)	OFF (H)	16-bit right justified
OFF (H)	ON (L)	24-bit right justified
ON (L)	OFF (H)	24-bit I <sup>2</sup> S (default)
ON (L)	ON (L)	24-bit left justified

**Table 1-11. SW006: DIT4096 Channel Status Information Control<sup>(1)</sup>**

SW006	DESCRIPTION
CSS	Channel status data mode input (default: on)
COPY-C	Copy protect or channel status data input (default: on)
U	User data input (default: on)
V	Validity data input (default: on)
L	Generation status input (default: on)
/AUDIO	Audio data valid control input (default: on)
/EMPH	Pre-emphasis status input (default: off)
BLSM	Block start mode control input (default: off)
BLS	Block start I/O (default: off)

<sup>(1)</sup> Control of these switches is not required for PCM3052A function and performance evaluation.

**Table 1-12. SW053: Mode Control**

SW053	DESCRIPTION
RESET	Function control that is defined on RESET (default: off)
MDI	Function control that is defined on MDI (default: off)
MC	Function control that is defined on MC (default: off)
ML	Function control that is defined on ML (default: off)

**Table 1-13. JP051: DOUTS or MDO Setting for Mode Control**

JP051	DESCRIPTION
1/4	Change SCL configuration to MC configuration (default: off)
2/4	Change SCA configuration to MD configuration (default: off)
3/4	Enable MDO (default: off)
4/4	Enable DOUTS (default: on)

**Table 1-14. JP109: DUT (PCM3052A) V<sub>CC</sub> Supply Voltage Selection**

JP109	DESCRIPTION
LEFT	DUT V <sub>CC</sub> is supplied from external 5 V (default).
RIFHT	DUT V <sub>CC</sub> is supplied from onboard 4.5-V regulator

**Table 1-15. JP110: MIC Input Configuration**

JP110	DESCRIPTION
LEFT	Single-ended microphone input
RIFHT	Differential microphone input (default)

**Table 1-16. JP101-104: Lineout LPF Selection**

JP101,102,103,104	DESCRIPTION
OFF	40-kHz BW
ON	20-kHz BW (default)

**Table 1-17. JP105, JP106: ADC Input Level Selection**

JP105,106	DESCRIPTION
1 Vrms	1.06-Vrms full-scale voltage on ADC inputs (default)
2 Vrms	2.12-Vrms full-scale voltage on ADC inputs

**Table 1-18. JP107: Bridge for PCM Audio Interface**

JP107	DESCRIPTION
ON	All straps must be mounted for interfacing onboard SPDIF receiver/transmitter.
OFF	All straps must be removed and connecting external audio interface signals on JP107 (signal) – JP111 (GND) for interfacing with external equipment.

**Table 1-19. JP108: Bridge for Mode Control Interface**

JP108	DESCRIPTION
ON	All straps must be mounted for interfacing with PC via CN060.
OFF	All straps must be removed and connecting external control interface signals on right-side of JP108 for interfacing with external equipment.


### 1.2.3 DEM-DAI3052A EVM Operation

#### Start

Run EVM control software by double clicking REGTEST\_I<sup>2</sup>C.


#### Initialization

Click pulldown menu, and select "High" for "ENABLE(L)", "High-Pulse" for "SCL(C)", "SDA(D)", and "Low-Pulse" for "Reset(R)" for standard control.



#### Send Command

Click box, which should be set to "1", so that address and data is set to desired value. Click pulldown menu, "Execute (E)", and select "Send (S)", so that command that is already set up is sent through the printer port.




---

*Typical Performance and Measurement Example*


### 1.3 Typical Performance and Measurement Example

The following graphs show typical performance and FFT results for the ADC and DAC.

PCM3052A, DAC, 48 kHz, 0 dB




PCM3052A, DAC, 48 kHz, -60 dB




Typical Performance and Measurement Example

PCM3052A, ADC, 48 kHz, Line, -0.5 dB




PCM3052A, ADC, 48 kHz, Line, -60 dB




Typical Performance and Measurement Example

PCM3052A, ADC, 48 kHz, Mic, No input signal



PCM3052A, ADC, 48 kHz, Mic with 20 dB gain, No input signal



*Typical Performance and Measurement Example*

---

## ***Schematics and Printed Circuit Boards***

This chapter presents the DEM-DAI3052A schematics, Bill of Materials (BOM), and printed circuit boards.

Topic	Page
2.1 DEM-DAI3052A Schematics .....	20
2.2 DEM-DAI3052A Bill of Materials (BOM) .....	24
2.3 DEM-DAI3052A Printed Circuit Boards.....	27

## 2.1 DEM-DAI3052A Schematics




Figure 2-1. DEM-DAI3052A Power and Interface Section





Figure 2-2. DEM-DAI3052A Digital Section (Digital Audio Interface)

*DEM-DAI3052A Schematics*



**Figure 2-3. DEM-DAI3052A Analog Section**




Figure 2-4. DEM-DAI3052A DUT Section

## 2.2 DEM-DAI3052A Bill of Materials (BOM)

REFERENCE DESIGNATORS	PART DESCRIPTION	MANUFACTURER PART NO.	SPECIFICATION	MANUFACTURER	QTY
D001, D051, D052, D053, D054, D055	Diode	1SS133		ROHM	6
D101	LED	TLSU124(F)		Toshiba	1
U001	Hex Unbuffered Inverter	SN74HCU04NS		TI	1
U002	Digital Interface Receiver	DIR1703DB		TI	1
U003, U051	3.3-V Regulator	REG1117-3.3		TI	2
U004	Digital Interface Transmitter	DIT4096PW		TI	1
U005	Octal Buffer Driver	SN74HCT244NS		TI	1
U052	TOSLINK Optical Transmitter	TOTX179P		Toshiba	1
U053	TOSLINK Optical Receiver	TORX179P		Toshiba	1
U054	Octal Buffer Driver	SN74LVC244ANS		TI	1
U101, U102, U103	Op Amp	OPA2134PA		TI	3
U104	Regulator IC	REG103GA-A		TI	1
U151	Stereo Audio Codec	PCM3052A	(DUT)	TI	1
X001	Crystal Resonator	HC-49/U-S-24.576 MHz	24.576 MHz	Kinseki	1
C001, C061	Polyester Film Capacitor	AMCF0050J104	0.1 uF	Nissei Electronic	2
C012	Polyester Film Capacitor	AMZF0050J683	0.068 uF	Nissei Electronic	1
C013	Polyester Film Capacitor	AMCF0050J822	8200 pF	Nissei Electronic	1
C103, C104, C105, C106	Polypropylene Film Capacitor	APSF0100J122	1200 pF	Nissei Electronic	4
C107, C108, C109, C110	Polypropylene Film Capacitor	APSF0100J121	120 pF	Nissei Electronic	4
C115, C116	Polypropylene Film Capacitor	APSF0100J182	1800 pF	Nissei Electronic	2
C117, C118	Polypropylene Film Capacitor	APSF0100J331	330 pF	Nissei Electronic	2
C119, C120	Polypropylene Film Capacitor	APSF0100J101	100 pF	Nissei Electronic	2
C002, C004, C018, C051, C055, C057, C059, C062, C127, C021, C064	Ceramic Capacitor	RPEF11H104Z2K1A01B	0.1 uF	Murata	11
C006, C007	Ceramic Capacitor	RPE2C1H180J2P1Z01B	18 pF	Murata	2
C129	Ceramic Capacitor	RPER11H103K2P1A01B	0.01 uF	Murata	1
C009, C011, C014, C016, C161, C162, C163, C164, C167, C168, C169, C170	Chip Ceramic Capacitor	GRM188B11E104KA01	0.1 uF/25 V 1608 type	Murata	12
C003, C005, C008, C010, C015, C017, C056, C058, C060, C063, C111, C112, C123, C124, C125, C126, C128, C151, C152, C153, C154, C155, C156, C157, C158, C165	Electrolytic Capacitor	R3A-16V100M	10 uF/16 V	ELNA	26
C052, C053, C054	Electrolytic Capacitor	ROA-16V101M	100 uF/16 V	ELNA	3
C101, C102, C113, C114, C121, C122	Electrolytic Capacitor	ROA-16V100M	10 uF/16 V	ELNA	6
C159, C160	Electrolytic Capacitor	UEP1H010MDT	1 uF, Bi-polar	Nichicon	2
R001, R003	Metal Film Resistor	MFS1/4CC-47kΩF	1/8 W, 47 kΩ	KOA	2
R002	Metal Film Resistor	MFS1/4CC-2.2kΩF	1/8 W, 2.2 kΩ	KOA	1


REFERENCE DESIGNATORS	PART DESCRIPTION	MANUFACTURER PART NO.	SPECIFICATION	MANUFACTURER	QTY
R004, R056	Metal Film Resistor	MFS1/4CC-470 $\Omega$ F	1/8 W, 470 $\Omega$	KOA	2
R005	Metal Film Resistor	MFS1/4CC-1M $\Omega$ F	1/8 W, 1 M $\Omega$	KOA	1
R006, R113, R114	Metal Film Resistor	MFS1/4CC-1.2k $\Omega$ F	1/8 W, 1.2 k $\Omega$	KOA	3
R051	Metal Film Resistor	MFS1/4CC-90.9 $\Omega$ F	1/8 W, 90.9 $\Omega$	KOA	1
R052	Metal Film Resistor	MFS1/4CC-374 $\Omega$ F	1/8 W, 374 $\Omega$	KOA	1
R053	Metal Film Resistor	MFS1/4CC-75 $\Omega$ F	1/8 W, 75 $\Omega$	KOA	1
R054, R055, R101, R102	Metal Film Resistor	MFS1/4CC-10k $\Omega$ F	1/8 W, 10 k $\Omega$	KOA	4
R103, R104, R151, R152	Metal Film Resistor	MFS1/4CC-1k $\Omega$ F	1/8 W, 1 k $\Omega$	KOA	4
R105, R106	Metal Film Resistor	MFS1/4CC-15k $\Omega$ F	1/8 W, 15 k $\Omega$	KOA	2
R107, R108, R119, R120, R121, R122, R123, R124, R125, R126	Metal Film Resistor	MFS1/4CC-100 $\Omega$ F	1/8 W, 100 $\Omega$	KOA	10
R109, R110	Metal Film Resistor	MFS1/4CC-2.4k $\Omega$ F	1/8 W, 2.4 k $\Omega$	KOA	2
R111, R112, R129	Metal Film Resistor	MFS1/4CC-3.3k $\Omega$ F	1/8 W, 3.3 k $\Omega$	KOA	3
R115, R116, R117, R118	Metal Film Resistor	MFS1/4CC-4.7k $\Omega$ F	1/8 W, 4.7 k $\Omega$	KOA	4
R127	Metal Film Resistor	MFS1/4CC-49.9k $\Omega$ F	1/8 W, 49.9 k $\Omega$	KOA	1
R128	Metal Film Resistor	MFS1/4CC-20k $\Omega$ F	1/8 W, 20 k $\Omega$	KOA	1
RA001, RA051	Resistor Array	M6-1-473J	47 k $\Omega$ $\times$ 5	Beckman	2
RA002	Resistor Array	M4-1-473J	47 k $\Omega$ $\times$ 3	Beckman	1
RA003	Resistor Array	M10-1-473J	47 k $\Omega$ $\times$ 9	Beckman	1
TR001	Pulse Transformer	DA-02		JPC	1
CN001	10-Pin Pin Header	FFC-10AMEP1		Honda Tsushin	1
CN002	9-Pin Pin Header	FFC-9AMEP1		Honda Tsushin	1
CN051	Banana Jack (Orange)	T-45 (Orange)		Sato Parts	1
CN052	Banana Jack (Green)	T-45 (Green)		Sato Parts	1
CN053	Banana Jack (Blue)	T-45 (Blue)		Sato Parts	1
CN054	Banana Jack (Red)	T-45 (Red)		Sato Parts	1
CN055	Banana Jack (Black)	T-45 (Black)		Sato Parts	1
CN056	2-Pin VH Connector	B2P-VH(LF)(SN)		JST	1
CN057	2-Pin Pin Header	FFC-2BMEP1		Honda Tsushin	1
CN058, CN059	RCA Connector (Yellow)	LPR6520-0804 (Yellow)		SMK	2
CN060	Ribbon Connector (Centronics)	57LE40360-7700(D3)-FA		DDK	1
CN101, CN105	RCA Connector (White)	LPR6520-0803 (White)		SMK	2
CN102, CN106	RCA Connector (Red)	LPR6520-0802 (Red)		SMK	2
CN103	3.5 mm Stereo Min Plug	YKB21-5274B		JALCO	1
CN104	2-Pin Pin Header	FFC-2AMEP1		Honda Tsushin	1
JP001	10-Pin Pin Header	FFC-10BMEP1		Honda Tsushin	1
JP002	3-Pin Pin Header	FFC-3AMEP1		Honda Tsushin	1
JP051	8-Pin Pin Header	FFC-8BMEP1		Honda Tsushin	1
JP101, JP102, JP105, JP106, JP109, JP110	4-Pin Pin Header	FFC-4BMEP1		Honda Tsushin	6
JP103, JP104	2-Pin Pin Header	FFC-2BMEP1		Honda Tsushin	2
JP107	18-Pin Pin Header	FFC-18NSM1		Honda Tsushin	1

*DEM-DAI3052A Bill of Materials (BOM)*


---

REFERENCE DESIGNATORS	PART DESCRIPTION	MANUFACTURER PART NO.	SPECIFICATION	MANUFACTURER	QTY
JP108	12-Pin Pin Header	FFC-12BMEP1		Honda Tsushin	1
	Short Plug	DIC-130		Honda Tsushin	28
SW001, SW051, SW052	Toggle Switch (DPDT)	FT1D-2M-Z		Fujisoku	3
SW002, SW054	Push Switch	FP1F-2M-Z		Fujisoku	2
SW003, SW053	DIP Switch	DSS104	4 elements	Fujisoku	2
SW004	Toggle Switch (DPDT With Neutral)	FT1E-2M-Z		Fujisoku	1
SW005	DIP Switch	DSS108	8 elements	Fujisoku	1
SW006	DIP Switch	DSS110	10 elements	Fujisoku	1

### **2.3 DEM-DAI3052A Printed Circuit Boards**



**Figure 2-5. DEM-DAI3052A Top Silkscreen**




Figure 2-6. DEM-DAI3052A Top Copper





Figure 2-7. DEM-DAI3052A Bottom Copper

*DEM-DAI3052A Printed Circuit Boards*



**Figure 2-8. DEM-DAI3052A Form, Dimension, and Drill**

## EVM TERMS AND CONDITIONS

Texas Instruments (TI) provides the enclosed Evaluation Module and related material (EVM) to you, the user, (you or user) **SUBJECT TO** the terms and conditions set forth below. By accepting and using the EVM, you are indicating that you have read, understand and agree to be bound by these terms and conditions. **IF YOU DO NOT AGREE TO BE BOUND BY THESE TERMS AND CONDITIONS, YOU MUST RETURN THE EVM AND NOT USE IT.**

This EVM is provided to you by TI and is intended for your **INTERNAL ENGINEERING DEVELOPMENT OR EVALUATION PURPOSES ONLY**. It is provided "AS IS" and "WITH ALL FAULTS." It is not considered by TI to be fit for commercial use. As such, the EVM may be incomplete in terms of required design-, marketing-, and/or manufacturing-related protective considerations, including product safety measures typically found in the end product. As a prototype, the EVM does not fall within the scope of the European Union directive on electromagnetic compatibility and therefore may not meet the technical requirements of the directive.

Should this EVM not meet the specifications indicated in the EVM User's Guide, it may be returned within 30 days from the date of delivery for a full refund of any amount paid by user for the EVM, which user agrees shall be user's sole and exclusive remedy. **THE FOREGOING WARRANTY IS THE EXCLUSIVE WARRANTY MADE BY TI TO USER, AND IS IN LIEU OF ALL OTHER WARRANTIES, EXPRESSED, IMPLIED, OR STATUTORY, INCLUDING ANY WARRANTY OF MERCHANTABILITY, FITNESS FOR ANY PARTICULAR PURPOSE OR NON-INFRINGEMENT.**

TI shall have no obligation to defend any claim arising from the EVM, including but not limited to claims that the EVM infringes third party intellectual property. Further, TI shall have no liability to user for any costs, losses or damages resulting from any such claims. User shall indemnify and hold TI harmless against any damages, liabilities or costs resulting from any claim, suit or proceeding arising from user's handling or use of the EVM, including but not limited to, (i) claims that the EVM infringes a third party's intellectual property, and (ii) claims arising from the user's use or handling of the EVM. TI shall have no responsibility to defend any such claim, suit or proceeding.

User assumes all responsibility and liability for proper and safe handling and use of the EVM and the evaluation of the EVM. TI shall have no liability for any costs, losses or damages resulting from the use or handling of the EVM. User acknowledges that the EVM may not be regulatory compliant or agency certified (FCC, UL, CE, etc.). Due to the open construction of the EVM it is the user's responsibility to take any and all appropriate precautions with regard to electrostatic discharge.

**EXCEPT TO THE EXTENT OF THE USER'S INDEMNITY OBLIGATIONS SET FORTH ABOVE, NEITHER PARTY SHALL BE LIABLE TO THE OTHER FOR ANY INDIRECT, SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES WHETHER TI IS NOTIFIED OF THE POSSIBILITY OR NOT.**

TI currently deals with a variety of customers for products, and therefore our arrangement with the user **is not exclusive**.

**TI assumes no liability for applications assistance, customer product design, software performance, or infringement of patents or services described herein.**

User agrees to read the EVM User's Guide and, specifically, the EVM warnings and Restrictions notice in the EVM User's Guide prior to handling the EVM and the product. This notice contains important safety information about temperatures and voltages.

It is user's responsibility to ensure that persons handling the EVM and the product have electronics training and observe good laboratory practice standards.

By providing user with this EVM, product and services, TI is NOT granting user any license in any patent or other intellectual property right.

Mailing Address: Texas Instruments, Post Office Box 655303, Dallas, Texas 75265  
Copyright © 2006, Texas Instruments Incorporated

### **EVM WARNINGS AND RESTRICTIONS**

It is important to operate this EVM within the input voltage range and the output voltage range that is less than 120% of the corresponding nominal voltage ranges described in the EVM user's guide.

Exceeding the specified input range may cause unexpected operation and/or irreversible damage to the EVM. If there are questions concerning the input range, please contact a TI field representative prior to connecting the input power.

Applying loads outside of the specified output range may result in unintended operation and/or possible permanent damage to the EVM. Please consult the EVM User's Guide prior to connecting any load to the EVM output. If there is uncertainty as to the load specification, please contact a TI field representative.

During normal operation, some circuit components may have case temperatures greater than 50°C. The EVM is designed to operate properly with certain components above 50°C as long as the input and output ranges are maintained. These components include but are not limited to linear regulators, switching transistors, pass transistors, and current sense resistors. These types of devices can be identified using the EVM schematic located in the EVM User's Guide. When placing measurement probes near these devices during operation, please be aware that these devices may be very warm to the touch.

Mailing Address: Texas Instruments, Post Office Box 655303, Dallas, Texas 75265  
Copyright © 2006, Texas Instruments Incorporated

## IMPORTANT NOTICE

Texas Instruments Incorporated and its subsidiaries (TI) reserve the right to make corrections, modifications, enhancements, improvements, and other changes to its products and services at any time and to discontinue any product or service without notice. Customers should obtain the latest relevant information before placing orders and should verify that such information is current and complete. All products are sold subject to TI's terms and conditions of sale supplied at the time of order acknowledgment.

TI warrants performance of its hardware products to the specifications applicable at the time of sale in accordance with TI's standard warranty. Testing and other quality control techniques are used to the extent TI deems necessary to support this warranty. Except where mandated by government requirements, testing of all parameters of each product is not necessarily performed.

TI assumes no liability for applications assistance or customer product design. Customers are responsible for their products and applications using TI components. To minimize the risks associated with customer products and applications, customers should provide adequate design and operating safeguards.

TI does not warrant or represent that any license, either express or implied, is granted under any TI patent right, copyright, mask work right, or other TI intellectual property right relating to any combination, machine, or process in which TI products or services are used. Information published by TI regarding third-party products or services does not constitute a license from TI to use such products or services or a warranty or endorsement thereof. Use of such information may require a license from a third party under the patents or other intellectual property of the third party, or a license from TI under the patents or other intellectual property of TI.

Reproduction of information in TI data books or data sheets is permissible only if reproduction is without alteration and is accompanied by all associated warranties, conditions, limitations, and notices. Reproduction of this information with alteration is an unfair and deceptive business practice. TI is not responsible or liable for such altered documentation.

Resale of TI products or services with statements different from or beyond the parameters stated by TI for that product or service voids all express and any implied warranties for the associated TI product or service and is an unfair and deceptive business practice. TI is not responsible or liable for any such statements.

Following are URLs where you can obtain information on other Texas Instruments products and application solutions:

<b>Products</b>		<b>Applications</b>	
Amplifiers	<a href="http://amplifier.ti.com">amplifier.ti.com</a>	Audio	<a href="http://www.ti.com/audio">www.ti.com/audio</a>
Data Converters	<a href="http://dataconverter.ti.com">dataconverter.ti.com</a>	Automotive	<a href="http://www.ti.com/automotive">www.ti.com/automotive</a>
DSP	<a href="http://dsp.ti.com">dsp.ti.com</a>	Broadband	<a href="http://www.ti.com/broadband">www.ti.com/broadband</a>
Interface	<a href="http://interface.ti.com">interface.ti.com</a>	Digital Control	<a href="http://www.ti.com/digitalcontrol">www.ti.com/digitalcontrol</a>
Logic	<a href="http://logic.ti.com">logic.ti.com</a>	Military	<a href="http://www.ti.com/military">www.ti.com/military</a>
Power Mgmt	<a href="http://power.ti.com">power.ti.com</a>	Optical Networking	<a href="http://www.ti.com/opticalnetwork">www.ti.com/opticalnetwork</a>
Microcontrollers	<a href="http://microcontroller.ti.com">microcontroller.ti.com</a>	Security	<a href="http://www.ti.com/security">www.ti.com/security</a>
		Telephony	<a href="http://www.ti.com/telephony">www.ti.com/telephony</a>
		Video & Imaging	<a href="http://www.ti.com/video">www.ti.com/video</a>
		Wireless	<a href="http://www.ti.com/wireless">www.ti.com/wireless</a>

Mailing Address: Texas Instruments, Post Office Box 655303, Dallas, Texas 75265

Copyright © 2006, Texas Instruments Incorporated