

2-GBPS Differential Repeater Evaluation Module

User's Guide

November 2002

High-Performance Linear/Interface Products

SLLU040A

IMPORTANT NOTICE

Texas Instruments Incorporated and its subsidiaries (TI) reserve the right to make corrections, modifications, enhancements, improvements, and other changes to its products and services at any time and to discontinue any product or service without notice. Customers should obtain the latest relevant information before placing orders and should verify that such information is current and complete. All products are sold subject to TI's terms and conditions of sale supplied at the time of order acknowledgment.

TI warrants performance of its hardware products to the specifications applicable at the time of sale in accordance with TI's standard warranty. Testing and other quality control techniques are used to the extent TI deems necessary to support this warranty. Except where mandated by government requirements, testing of all parameters of each product is not necessarily performed.

TI assumes no liability for applications assistance or customer product design. Customers are responsible for their products and applications using TI components. To minimize the risks associated with customer products and applications, customers should provide adequate design and operating safeguards.

TI does not warrant or represent that any license, either express or implied, is granted under any TI patent right, copyright, mask work right, or other TI intellectual property right relating to any combination, machine, or process in which TI products or services are used. Information published by TI regarding third-party products or services does not constitute a license from TI to use such products or services or a warranty or endorsement thereof. Use of such information may require a license from a third party under the patents or other intellectual property of the third party, or a license from TI under the patents or other intellectual property of TI.

Reproduction of information in TI data books or data sheets is permissible only if reproduction is without alteration and is accompanied by all associated warranties, conditions, limitations, and notices. Reproduction of this information with alteration is an unfair and deceptive business practice. TI is not responsible or liable for such altered documentation.

Resale of TI products or services with statements different from or beyond the parameters stated by TI for that product or service voids all express and any implied warranties for the associated TI product or service and is an unfair and deceptive business practice. TI is not responsible or liable for any such statements.

Mailing Address:

Texas Instruments Post Office Box 655303 Dallas, Texas 75265

Copyright © 2002, Texas Instruments Incorporated

EVM IMPORTANT NOTICE

Texas Instruments (TI) provides the enclosed product(s) under the following conditions:

This evaluation kit being sold by TI is intended for use for **ENGINEERING DEVELOPMENT OR EVALUATION PURPOSES ONLY** and is not considered by TI to be fit for commercial use. As such, the goods being provided may not be complete in terms of required design-, marketing-, and/or manufacturing-related protective considerations, including product safety measures typically found in the end product incorporating the goods. As a prototype, this product does not fall within the scope of the European Union directive on electromagnetic compatibility and therefore may not meet the technical requirements of the directive.

Should this evaluation kit not meet the specifications indicated in the EVM User's Guide, the kit may be returned within 30 days from the date of delivery for a full refund. THE FOREGOING WARRANTY IS THE EXCLUSIVE WARRANTY MADE BY SELLER TO BUYER AND IS IN LIEU OF ALL OTHER WARRANTIES, EXPRESSED, IMPLIED, OR STATUTORY, INCLUDING ANY WARRANTY OF MERCHANTABILITY OR FITNESS FOR ANY PARTICULAR PURPOSE.

The user assumes all responsibility and liability for proper and safe handling of the goods. Further, the user indemnifies TI from all claims arising from the handling or use of the goods. Please be aware that the products received may not be regulatory compliant or agency certified (FCC, UL, CE, etc.). Due to the open construction of the product, it is the user's responsibility to take any and all appropriate precautions with regard to electrostatic discharge.

EXCEPT TO THE EXTENT OF THE INDEMNITY SET FORTH ABOVE, NEITHER PARTY SHALL BE LIABLE TO THE OTHER FOR ANY INDIRECT, SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES.

TI currently deals with a variety of customers for products, and therefore our arrangement with the user **is not exclusive**.

TI assumes no liability for applications assistance, customer product design, software performance, or infringement of patents or services described herein.

Please read the EVM User's Guide and, specifically, the EVM Warnings and Restrictions notice in the EVM User's Guide prior to handling the product. This notice contains important safety information about temperatures and voltages. For further safety concerns, please contact the TI application engineer.

Persons handling the product must have electronics training and observe good laboratory practice standards.

No license is granted under any patent right or other intellectual property right of TI covering or relating to any machine, process, or combination in which such TI products or services might be or are used.

Mailing Address:

Texas Instruments Post Office Box 655303 Dallas, Texas 75265

Copyright © 2002, Texas Instruments Incorporated

EVM WARNINGS AND RESTRICTIONS

It is important to operate this EVM within the supply voltage range of 3 V to 3.6 V.

Exceeding the specified input range may cause unexpected operation and/or irreversible damage to the EVM. If there are questions concerning the supply range, please contact a TI field representative prior to connecting the input power.

Applying loads outside of the specified output range may result in unintended operation and/or possible permanent damage to the EVM. Please consult the EVM User's Guide prior to connecting any load to the EVM output. If there is uncertainty as to the load specification, please contact a TI field representative.

During normal operation, some circuit components may have case temperatures greater than 125°C. The EVM is designed to operate properly with certain components above 125°C as long as the input and output ranges are maintained. These components include but are not limited to linear regulators, switching transistors, pass transistors, and current sense resistors. These types of devices can be identified using the EVM schematic located in the EVM User's Guide. When placing measurement probes near these devices during operation, please be aware that these devices may be very warm to the touch.

Mailing Address:

Texas Instruments Post Office Box 655303 Dallas, Texas 75265

Copyright © 2002, Texas Instruments Incorporated

Preface

Read This First

About This Manual

This EVM user's guide provides information about the 2-GBPS differential repeater evaluation module.

How to Use This Manual

This document contains the following chapters:

- □ Chapter 1 Introduction
- Chapter2 Setup and Equipment Required
- □ Chapter 3 EVM Construction

Information About Cautions and Warnings

This book may contain cautions and warnings.

This is an example of a caution statement.

A caution statement describes a situation that could potentially damage your software or equipment.

This is an example of a warning statement.

A warning statement describes a situation that could potentially cause harm to <u>you</u>.

The information in a caution or a warning is provided for your protection. Please read each caution and warning carefully.

Related Documentation From Texas Instruments

To obtain a copy of any of the following TI document, call the Texas Instruments Literature Response Center at (800) 477-8924 or the Product Information Center (PIC) at (972) 644-5580. When ordering, identify this booklet by its title and literature number. Updated documents can also be obtained through our website at www.ti.com.

Data Sheet:	Literature Number:
SN65LVDS100/101	SLLS516
SN65CML100	SLLS547

FCC Warning

This equipment is intended for use in a laboratory test environment only. It generates, uses, and can radiate radio frequency energy and has not been tested for compliance with the limits of computing devices pursuant to subpart J of part 15 of FCC rules, which are designed to provide reasonable protection against radio frequency interference. Operation of this equipment in other environments may cause interference with radio communications, in which case the user at his own expense will be required to take whatever measures may be required to correct this interference.

Contents

1	Intro	duction	1-1
	1.1	Overview	1-2
	1.2	Signal Paths	1-3
2	Setu	p and Equipment Required	2-1
	2.1	Overview	2-2
	2.2	Applying an Input	2-3
	2.3	Observing an Output	2-5
	2.4	Typical Test Results	2-6
3	EVM	Construction	3-1
	3.1	Schematic	3-2
	3.2	Bill of Materials	3-3
	3.3	Board Stackup	3-4
	3.4	Board Layer Patterns	3-5

Figures

1-1	EVM With SN65LVDS100 Installed	1-2
1-2	Schematic of EVM Signal Path	1-3
2-1	TIA/EIA-644-A LVDS Driver Test Load	2-2
2-2	EVM Power Connections for SN65LVDS100 Evaluation	2-3
2-3	External Termination for Differential CML or LVPECL Inputs to EVM	2-4
2-4	External Termination for Single-Ended LVPECL Inputs to EVM	2-5
2-5	Typical Output From SN65LVDS100 EVM	2-7

Tables

		1 0
1-1	Ordering information	 1-2

Chapter 1

Introduction

The 2-GBPS differential repeater evaluation module (EVM) allows evaluation of the SN65LVDS100, SN65LVDS101, and SN65CML100 differential repeaters/ translators. This user's guide gives a brief overview of the EVM, setup and operation instructions, and typical test results that can be expected.

Торіс				
1.1	Overview 1-2			
1.2	Signal Paths 1-3			

1.1 Overview

The 2-GBPS differential repeater evaluation module (EVM) is designed for evaluation of the SN65LVDS100, SN65LVDS101, and SN65CML100 differential repeaters/ translators. The SN65LVDS100 and SN65LVDS101 devices both incorporate wide common-mode range receivers, allowing receipt of LVDS, LVPECL, or CML input signals. The SN65LVDS100 provides an LVDS output, the SN65LVDS101 incorporates an LVPECL output driver, and the SN65CML100 delivers a CML output. Both devices provide a V_{BB} reference voltage to support receiving of single-ended LVPECL input signals, or biasing of ac-coupled inputs. The EVM can be ordered with the SN65LVDS100, SN65LVDS101, or SN65CML100 installed. Orderable EVM part numbers are shown in Table 1-1.

Table 1-1. Ordering Information

EVM Part Number	Installed Device
SN65LVDS100EVM	SN65LVDS100DGK
SN65LVDS101EVM	SN65LVDS101DGK
SN65CML100EVM	SN65CML100DGK

Detailed information relating to the SN65LVDS100, SN65LVDS101, and SN65CML100 can be found in the device data sheet, a copy of which is shipped as part of the EVM or available from www.ti.com. A picture of the EVM, with an SN65LVDS100 device installed, is shown in Figure 1-1.

Figure 1-1. EVM With SN65LVDS100 Installed



1.2 Signal Paths

A partial schematic of the EVM is shown in Figure 1-2 and a full schematic is in chapter 3. Edge-mount SMA connectors (J4, J5, J6, and J7) are provided for data input and output connections. Three power jacks (J1, J2, and J3) are used to provide power to and a ground reference, for the EVM. The use of these power jacks is addressed later. Chapter 3 also provides a parts list for the EVM, as well as an indication of which components are installed when shipped.



Figure 1-2. Schematic of EVM Signal Path

Chapter 2

Setup and Equipment Required

This chapter examines the setup and use of the evaluation module and the results of operation.

Торі	c Page
2.1	Overview
2.2	Applying an Input
2.3	Observing an Output 2-5
2.4	Typical Test Results

2.1 Overview

LVDS driver output characteristics are specified in the TIA/EIA-644 standard. LVDS drivers nominally provide a 350-mV differential signal, with a 1.25-V offset from ground. These levels are attained when driving a 100- Ω differential line-termination test load (see Figure 2-1). In real applications, there may be a ground potential between a driver and receiver(s). The driver must drive the common-mode load presented by the receiver inputs and the differential load. A TIA/EIA-644-A compliant LVDS driver is required to maintain its differential output with up to 32 standard receivers. The receiver load is represented by the 3.74-k Ω resistors shown in Figure 2-1.

Figure 2-1. TIA/EIA-644-A LVDS Driver Test Load



LVPECL drivers are generally loaded with 50- Ω resistors to a termination bias voltage, V_T. V_T is usually 2-V below the supply voltage of the driver circuit. When the driver operates from a 3.3-V supply, V_T is set to approximately 1.3 V.

CML drivers are generally loaded with 50- Ω resistors to a termination voltage, V_{TT}. V_{TT} can either be equivalent to the supply voltage of the driver circuit (equal to V_{CC}) or set to 2.5 V or 1.8 V, irrelevant to the supply voltage. If desired, the SN65CML100 can be configured to drive a dual 50- Ω load. In this configuration one 50- Ω resistor (tied to the termination voltage V_{TT}) is placed near the output of the SN65CML100 and a second 50- Ω resistor (also tied to V_{TT}) is placed near the end of the transmission line.

The EVM has been designed to support the SN65LVDS100 LVDS-output device, the SN65LVDS101 LVPECL-output device, and the SN65CML100 CML-output device. By using the three power jacks (J1, J2, and J3), as well as installing termination resistors (R2, R3, and R4), different methods of termination and probing can be used to evaluate the device output characteristics. The typical setup for the SN65LVDS100 is shown in Figure 2-2.



Figure 2-2. EVM Power Connections for SN65LVDS100 Evaluation

Warning Power jacks J1, J2, and J3 are not insulated on the backside of the EVM. Place on a nonconductive surface.

2.2 Applying an Input

LVDS inputs should be applied to SMA connectors J4 and J5, while keeping R1 installed. The EVM comes with a 100- Ω termination resistor (R1) installed across the differential inputs. This 100- Ω resistor represents an LVDS termination.

When using a general-purpose signal generator with $50-\Omega$ output impedance, make sure that the signal levels are between 0 V to 4 V with respect to J3. A signal generator such as the Advantest D3186 can simulate LVDS, LVPECL, or CML inputs.

When using LVPECL or CML drivers for the input signal, termination external to the EVM must be provided (see Figure 2-3). LVPECL drivers should be terminated with $50-\Omega$ pulldowns to V_T, while CML drivers should be terminated

with 50- Ω pullups to V_{TT}. When using external terminations, the onboard termination resistor R1 should be removed from the EVM. It should be noted that the signal quality at the receiver input may be degraded when external terminations are used, as a significant stub exists from the external termination network to the receiver input. The user needs to verify that the transition time of the input signal, coupled with the stub length, does not lead to reflection problems. These concerns would be addressed in a real application where the terminations are placed close to the receiver input.

Figure 2-3. External Termination for Differential CML or LVPECL Inputs to EVM



NOTES: A. Locate 50- Ω resistors as close to the EVM as possible B. Remove R1

Finally, as mentioned above, the SN65LVDS100, SN65LVDS101, and SN65CML100 devices provide a VBB reference voltage output. This output can be used with an externally terminated, single-ended, LVPECL input to convert from a single-ended input to a differential output. The same cautions that are mentioned above concerning signal quality and reflections apply. When using V_{BB} as a single-ended reference, R1 should be removed while R5 and JMP2 should be installed. The single-ended input signal is applied to J4. This setup directly connects the V_{BB} output to the DUT receiver B input via a $0-\Omega$ connection (see Figure 2-4).

Figure 2-4. External Termination for Single-Ended LVPECL Inputs to EVM



NOTES: A. Add jumper Jmp2 and 0- Ω R5 B. Remove R1

2.3 Observing an Output

Direct connection to an oscilloscope with $50-\Omega$ internal terminations to ground is accomplished without R2, R3, and R4¹. The outputs are available at J6 and J7 for direct connection to oscilloscope inputs. Matched length cables must be used when connecting the EVM to a scope to avoid inducing skew between the noninverting (+) and inverting (-) outputs.

The three power jacks (J1, J2, and J3) are used to provide power and a ground reference for the EVM. The power connections to the EVM determine the common-mode load to the device. As mentioned earlier, LVDS drivers have limited common-mode driver capability. When connecting the EVM outputs directly to oscilloscope inputs, setting of the oscilloscope common-mode offset voltage is required, as the oscilloscope presents low common-mode load impedance to the device.

Returning to Figure 2-2, power supply 1 is used to provide the required 3.3 V to the EVM. Power supply 2 is used to offset the EVM ground relative to the DUT ground. The EVM ground is connected to the oscilloscope ground through the returns on SMA connectors J6 and J7. With power applied as shown in Figure 2-2, the common-mode voltage seen by the SN65LVDS100 is approximately equal to the reference voltage being used inside the device preventing significant common-mode current to flow. Optimum device setup can be confirmed by adjusting the voltage on power supply 2 until its current is minimized. It is important to note that use of the dual supplies and offsetting the EVM ground relative to the DUT ground are simply steps needed for the test and evaluation of devices. Actual designs would include high-impedance receivers, which would not require the setup steps outlined above.

¹ As delivered R2, R3, and R4 are not installed

LVPECL drivers need a 50- Ω termination to V_T. A modification of Figure 2-2 and the above instructions are used when evaluating an SN65LVDS101 with a direct connection to a 50- Ω oscilloscope. With power supply 1 in Figure 2-2 set to 3.3 V, power supply 2 should be set to 1.3 V (2 V below V_{CC}) to provide the correct termination voltage.

CML drivers need a 50- Ω termination to V_{TT} (V_{TT} is either V_{CC}, 2.5 V, or 1.8 V). A modification of Figure 2-2 and the instructions for the SN65LVDS100 are used when evaluating a SN65CML100 with direct connection to a 50- Ω oscilloscope. With power supply 1 in Figure 2-2 set to 3.3 V, power supply 2 should be set to either V_{CC} (3.3 V), 2.5 V, or 1.8 V to provide the correct termination voltage.

Dual termination of the output can be achieved by placing 49.9- Ω resistors at R2 and R3 and connecting to an oscilloscope as described above.

If the EVM outputs are to be evaluated with a high-impedance probe, direct probing on the EVM is supported via installation of R2, R3, and R4. LVDS outputs can be observed by installing R4, a 100- Ω resistor. LVPECL outputs can be observed by installing R2 and R3 (49.9- Ω resistors), and setting power supply 2 to 1.3 V. CML outputs can be observed by setting power supply 2 to V_{TT} and installing 49.9- Ω resistors at R2 and R3 for single termination, or 24.9- Ω resistors at R2 and R3 for dual termination (Note that power supply 2 must be able to sink current.)

2.4 Typical Test Results

Figure 2-5 shows a typical test result obtained with the EVM. Figure 2-5 shows the output of an SN65LVDS100 being driven directly into a 50- Ω oscilloscope. For this figure, the SN65LVDS100 was stimulated with an HP 3-GBPS BERT. The input data was pseudorandom data at 2 GBPS and with a random record length of 2²³-1. The BERT drove two electrically matched one-meter cables with an electrical length of 3.667 ns. These cables were then connected to the EVM inputs. The EVM outputs were connected through another set of electrically matched one-meter cables and terminated by a TDS8000 oscilloscope's 50- Ω resistors to ground.



Figure 2-5. Typical Output From SN65LVDS100 EVM

Chapter 3

EVM Construction

This chapter lists the EVM components and examines the construction of the evaluation module.

Торі	ic Pa	ıge
3.1	Schematic	3-2
3.2	Bill of Materials	3-3
3.3	Board Stackup	3-4
3.4	Board Layer Patterns	3-5

3.1 Schematic



3.2 Bill of Materials

ITEM	QTY	MFG	MFG PART NO.	REF. DES.	DESCRIPTION	VALUE OR FUNCTION	NOT INSTALLED
1	2	Sprague	293D106X0035D2W	C1,C6	Capacitor, SMT, TANT	35 V, 10%, 10 μF	
2	2	AVX	12063G105ZATRA	C3,C8	Capacitor, SMT1206	25 V, 80 -20%, 1.0 μF	
3	2	AVX	12065C104JATMA	C4,C9	Capacitor, SMT1206	50 V, 5%, 0.1 μF	
4	2	Sprague	592D686X0010R2T	C2,C7	Capacitor, SMT, TANT	10 V, 20%, 68 μF, Low ESR	
5	2	Murata	GRM39X7R103K50V	C11, C12	Capacitor, SMT0603	50 V,±10%, 0.010 μF	
6	2	AVX	06033G102JATMA	C5,C10	Capacitor, SMT0603	25 V, 5%, 0.001 μF	
7	3	ITT-Pomona	3267	J1, J2, J3	Connector, banana jack	Bannana jack	
8	4	EF Johnson	142-0701-801	J4, J5, J6, J7	Connector	SMA Jack, end launch, 0.062	
9	1	Dale	CRCW0603100F	R1	Resistor, SMT,0603	100 Ω	
10	2			R2, R3	Resistor, SMT, 0603	49.9 Ω	R2, R3
11	1			R4	Resistor, SMT, 0603	100 Ω	R4
12	1			R5	Resistor, SMT, 0603	0 Ω	R5
13	1	AMP	4-103239-0x2	JMP2	Header	Male, 2 pin, 0.100 CC	
14	1	ТІ	SN65LVDS100 [†] SN65LVDS101 [†]	DUT1	IC, SMT, 8P	2-GBPS differential repeater/translator	
15	3				Screws		
16	3				Nuts		
17	1				User's manual		
18	1				Data sheet		

[†] Only one is installed

3.3 Board Stackup



6434666A PWA, BENCH, EVALUATION BOARD, SN65LVDS100/101D, EVM 10/31/01

3.4 Board Layer Patterns



Layer 1 - Signal/GND Fill (Top Side)



Layer 2 - GND Plane (INT1)



Layer 3 - V_{CC} Split Plane (INT2)



Layer 4 - GND Plane (Bottom Side)