


THIS DRAWING IS INTENDED TO HELP IN THE ASSEMBLY OF THE DESIGN.

REVISIONS				
ZONE	LTR	DESCRIPTION	DATE	APPROVED

1. REFER TO ODB++ FILE FOR SPECIFIC COMPONENT LOCATION INFORMATION.
2. USE WATER SOLUBLE FLUX DURING BOARD ASSEMBLY. ASSEMBLY MUST BE RoHS COMPLIANT AND LEAD FREE.
3. MARK BOARD'S SILKSCREEN WITH THE SERIAL NUMBER.
4. IPC-A-610 / ACCEPTABILITY OF ELECTRONIC ASSEMBLIES, CLASS2, CURRENT REVISION.
5. REMOVE THE METAL TAB ON THE BANANA JACKS BEFORE MOUNTING THEM ONE THE BOARD. USE LOCTITE THREADLOCKER BLUE 242 (OR EQUIVALENT) WHEN INSTALLING THE BANANAN JACKS.

SEE NOTE 3



UNLESS OTHERWISE SPECIFIED DIMENSIONS ARE IN INCHES TOLERANCES ARE: FRACTIONS DECIMALS ANGLES +/- .XX +/- .01 +/- .XXX +/- .005 +/-	CONTRACT NO.		TEXAS INSTRUMENTS INC.			
	APPROVALS					DATE
MATERIAL	DRAWN JV SMITH		10-18-16		ASSEMBLY DRAWING, ADC08351 EVM	
	ENG J SETON		10-18-16			
FINISH			SIZE	CODE IDENT NO.	DRAWING NO.	REV.
DO NOT SCALE DRAWING			D			A
SCALE						